





Standby/ON

When you connect the unit for the first time to the mains socket, it will be in standby mode and the Standby indicator will be red.

- Press the  button to switch ON the main unit.
- Press the  button again to switch the unit back into STANDBY mode. The POWER indicator will light up.
- Disconnect the mains plug from the mains socket if you want to switch OFF the unit completely.

Select the Play Mode

Press repeatedly the  button on the unit to switch between Bluetooth, USB, OPTICAL, COAXIAL, AUDIO IN and AUX(L/R). Alternatively press the , **USB, OPTI, COAX, AUDI** and **AUX** button on the remote control to select the desired source.

Note:

- If there is no signal, the unit will automatically switch off within 19 minutes to save energy.

Adjust the Volume


- Press the **VOL +/-** buttons to adjust the volume.
- If you want to turn off the sound, press the **MUTE** button on the remote control. Press the **MUTE** button again or press the **VOL +/-** button to resume normal listening.

Noted please, if you adjusted volume above 26, then power off and power on again, volume will restored to factory setting automatically.

Select the Sound Effect

- While playing, press the **MUSIC, NORMAL** or **NEWS** button on the remote control to select the desired preset equalizer.

AUX/AUDIO IN/COAXIAL/OPTICAL OPERATION

1. Press repeatedly the  button on the unit or press alternatively the **AUX, AUDI, COAX** and **OPTI** button on the remote control to select the desired source.
2. Operate your audio device directly for playback features.
3. Press the **VOL +/-** button to adjust the volume to your desired level.

Operation


Bluetooth Operation

You can listen to tracks from a media device if it is connected to the unit via Bluetooth.

Pair Bluetooth-enabled Devices

You need to pair your Bluetooth device with this unit before you connect them for the first time.

Note:

- The operational range between this unit and a Bluetooth device is approximately 8 meters (without any object between the Bluetooth device and the unit).
 - Before you connect a Bluetooth device to this unit, ensure that you know the device's capabilities.
 - Any obstacle between this unit and the Bluetooth device can reduce the operational range.
 - If the signal strength is weak, your Bluetooth device may disconnect, but it will re-enter automatically into pairing mode.
1. During ON mode, press the  button on the remote control to select the Bluetooth mode. If the unit is not paired to any Bluetooth device, the system enters automatically into pairing mode; or you need to press and hold the **PAIR** button to start pairing.
 2. Activate the Bluetooth function on your device and select the search mode.
"CELLO HT961" will appear on your Bluetooth device.
 3. Select "CELLO HT961" in the pairing list. After successful pairing, LED DISPLAY will display **bT**.

Tips:

- If there is already an existing connection, press the **PAIR** button on the remote control to re-activate the pairing mode. The existing connection will be interrupted.
- The unit will also be disconnected when your device is moved beyond the operational range.
- If you want to reconnect your device to this unit, place it within the operational range.
- If the device is moved beyond the operational range, when it is brought back, please check if the device is still connected to the unit.
- If the connection is lost, follow the above instructions to pair your device again to this unit.

USB Charging

You can plug an USB cable in USB socket to charge the mobile device. Output voltage and current is 5V/500mA.

Important note:

This device is equipped with an energy saving mode: if no signal is given during 19 minutes the device will switch automatically into standby mode in order to save energy (ERP 2 standard). Please note that low volume setting in the audio source may be recognized as "no audio signal": this will affect the capability of signal detection from the device and can also originate an automatic switch into standby mode. If this happens please reactivate the audio signal transmission or increase the volume setting on the audio source player (MP3 player, etc.), in order to resume playback. Please contact the local service center if the problem remains.

Trouble Shooting

To keep the warranty valid, never try to repair the system by yourself. If you encounter problems when using this unit, check the following points before requesting service.

No power

- Ensure that the mains cable is connected securely.
- Make sure that the unit is switched on.

The remote control does not function

- Use the remote control near to the unit.
- Point the remote control at the remote control sensor on the unit.
- Replace the batteries in the remote control with new ones.
- Remove any obstacles between the remote control and the unit.

Loud hum or noise is heard

• The plugs and sockets are dirty. Wipe them with a cloth slightly moistened with an appropriate non-abrasive cleaning solution.

The unit does not respond when pressing any buttons

- The unit may freeze up during use. Switch off and then switch on the unit again at the mains socket to reset it.

No sound output

- Make sure that the unit is not muted. Press **MUTE** or **VOL +** to resume normal listening.
- Ensure that the audio setting of the input source (e.g. TV, game console, DVD player, etc.) is set to PCM mode while using Optical connection.

I can't find the Bluetooth name of this unit on my Bluetooth device for Bluetooth pairing

- Ensure that the unit is switched on.
- Ensure that the Bluetooth function is activated on your Bluetooth device.
- The unit has a Bluetooth function that can receive a signal within 8 metres. Keep a distance within 8 metres both devices.

The unit switches off automatically during playing

- Please increase the volume level on your input source player like DVD player/TV ect.

Specifications

General

Power requirements: AC 100-240V~ 50/60Hz

Power consumption(on mode): 19 Watt

Power consumption(standby mode): < 0,5 Watt

Output power RMS: 80 Watt - 20W x 2 (speakers) + 40W (subwoofer)

Total harmonic distortion: <1%(1kHz, 1W)

Audio input sensitivity: 500mV

Frequency response: 40Hz - 20KHz

Main unit dimensions: 720 x 51 x 330 mm (W x H x D)

Speakers

Front Impedance: 8Ω x 2

Woofer Impedance: 4Ω

Bluetooth

Bluetooth version: V3.0

Work range: approx.10metres

Transmission frequency: 2.402~2.480GHz

Protocols: A2DP/AVRCP

Standard Accessories

Remote Control x 1pc

Instruction Manual x 1pc

RCA cable (White & Red) x 1pc

Optical cable x 1pc